

Command Center (Surface Mount)



System Includes Phone & Distribution Module

- 12 Zone 2500-12RC
- 16 Zone 2500-16RC
- 28 Zone 2500-28RC
- 36 Zone 2500-36RC
- 56 Zone 2500-56XRC
- 76 Zone 2500-76XRC
- 96 Zone 2500-96XRC
- 116 Zone 2500-116XRC

Dimensions:

- 2500-12RC, 16RC = 15.14" H x 12" W x 6.19" D
- 2500-28RC, 36RC, 56XRC, 76XRC, 96XRC, 116XRC = 21.03" H x 20.3" W x 5.19" D

Command Center (Desk Mount)



System Includes Phone & Distribution Module

- 12 Zone 2500-12NC
- 16 Zone 2500-16NC
- 28 Zone 2500-28NC
- 36 Zone 2500-36NC
- 56 Zone 2500-56XNC
- 76 Zone 2500-76XNC
- 96 Zone 2500-96XNC
- 116 Zone 2500-116XNC

Contact Us for Larger Projects

Command Center (Flush Mount)



System Includes Phone & Distribution Module

- 12 Zone 2500-12RCF
- 16 Zone 2500-16RCF
- 28 Zone 2500-28RCF
- 36 Zone 2500-36RCF
- 56 Zone 2500-56XRCF
- 76 Zone 2500-76XRCF
- 96 Zone 2500-96XRCF
- 116 Zone 2500-116XRCF

Dimensions:

2500-12RCF, 16RCF =

- **Front Frame:** 16.06" H x 14" W x 3.07" D

- **Back Box:** 15.64" H x 12" W x 3" D

2500-28RCF, 36RCF, 56XRCF, 76XRCF, 96XRCF, 116XRCF =

- **Front Frame:** 21.13" H x 25" W x 3.06" D

- **Back Box:** 20.66" H x 23" W x 3" D

Distribution Modules



12-36 Zone System



56-116 Zone System

- Included with Command Center
- Surface mount
- Install on a wall or table top
- Requires 120vac power with battery backup or RATH® Power Supply with battery backup
- Single dedicated phone line or as an Intercom System

Dimensions:

12-36 Zone System = 2.04" H x 17.28" W x 11.8" D

56-116 Zone System = 6.83" H x 17.18" W x 8.9" D

CODE COMPLIANCE:

- ADA, ASME A17, and B44 code compliant

POWER REQUIREMENTS:

- Command Center, Sub-Master Stations, and Machine Room Phones are powered from the Distribution Module (except SmartPhones)

WIRING REQUIREMENTS:

- Command Center, Sub-Master, and Machine Room Phone to Distribution Module requires a single pair
- Machine Room Phone (2300-630RC) requires a single pair
- SmartPhones to Distribution Module requires a single pair

PHONE CAPABILITIES:

- Calls wait in queue until previous call is disconnected and receive a message stating that an emergency call is in progress. When the prior call clears, the next phone in queue is connected.
- Includes handset and speaker phone for communication to phones
- Works with 2100 series SmartPhones
- LEDs indicate which phones have initiated a call
- Rescue personnel can communicate with individual phones and outside party

ADDITIONAL FEATURES:

- Standard system allows for a Command Center and a single Sub-Master (contact RATH® for additional Sub-Masters)
- Audible alert sounds when phones place a call until Command Center or Sub-Master Station joins conversation
- Can be configured with the main Command Center, multiple Sub-Master Stations (available in desk, surface, or flush mount), and Machine Room Phones (2300-630RC)

Specifications:

Mounting: Surface, flush, or desk

Design: Powder coated steel enclosure with twist lock closure

Warranty: 2 Years