

# Command Center Base Station

2500-\_\_NC Series



## Command Center (Desk Mount)



### System Includes Phone & Distribution Module

- 12 Zone 2500-12NC
- 16 Zone 2500-16NC
- 28 Zone 2500-28NC
- 36 Zone 2500-36NC
- 56 Zone 2500-56XNC
- 76 Zone 2500-76XNC
- 96 Zone 2500-96XNC
- 116 Zone 2500-116XNC

## Distribution Modules



### 12-36 Zone System

- Included with Command Center
- Surface mount
- Install on a wall or table top
- Requires 120vac power with battery backup or RATH® Power Supply with battery backup
- Single dedicated phone line or as an Intercom System

### 56-116 Zone System

#### Dimensions:

**12-36 Zone System** = 2.04" H x 17.28" W x 11.8" D  
**56-116 Zone System** = 6.83" H x 17.18" W x 8.9" D

**Contact Us for Larger Projects**

## CODE COMPLIANCE:

- International Building Code (IBC), National Fire Protection Association (NFPA) & Americans Disabilities Act (ADA)

## POWER REQUIREMENTS:

- Command Center and Sub-Master Stations are powered from the Distribution Module
- Command Center and Sub-Master to Distribution Module requires a single pair

## WIRING REQUIREMENTS:

- Command Center and Sub-Master to Distribution Module requires a single pair
- SmartPhones to Distribution Module requires a single pair

## PHONE CAPABILITIES:

- Calls wait in queue until previous call is disconnected and receive a message stating that an emergency call is in progress. When the prior call clears, the next phone in queue is connected.
- Includes handset and speaker phone for communication to Call Boxes
- Works with either our 2100 or 2400 series models with a single pair back to the Distribution Module. The 2400 Series is powered from the Distribution Module and the 2100 Series is powered from 2500-PWR24U.
- LEDs indicate which Call Boxes have initiated a call
- Rescue personnel can communicate with individual Call Boxes and outside party

## FEATURES:

- Standard system allows for a Command Center and a single Sub-Master (contact RATH® for additional Sub-Masters)
- Audible alert sounds when phones place a call until Command Center or Sub-Master Station joins conversation
- Can be configured with the main Command Center and multiple Sub-Master Stations (desk, surface, or flush mount)

### Specifications:

**Mounting:** Desk

**Design:** Powder coated steel enclosure with twist lock closure

**Warranty:** 2 Years