

Sub-Master Cabinet (Surface Mount)



- 12 Zone 2500-12B
- 16 Zone 2500-16B
- 28 Zone 2500-28B
- 36 Zone 2500-36B
- 56 Zone 2500-56XB
- 76 Zone 2500-76XB
- 96 Zone 2500-96XB
- 116 Zone 2500-116XB

Dimensions:

- **2500-12B, 16B:** 15.14" H x 12" W x 6.19" D
- **2500-28B, 36B, 56XB, 76XB, 96XB, 116XB:** 21.03" H x 20.3" W x 5.19" D

Sub-Master (Desk Mount)



- 12 Zone 2500-12D
- 16 Zone 2500-16D
- 28 Zone 2500-28D
- 36 Zone 2500-36D
- 56 Zone 2500-56XD
- 76 Zone 2500-76XD
- 96 Zone 2500-96XD
- 116 Zone 2500-116XB

Sub-Master Cabinet (Flush Mount)



- 12 Zone 2500-12F
- 16 Zone 2500-16F
- 28 Zone 2500-28F
- 36 Zone 2500-36F
- 56 Zone 2500-56XF
- 76 Zone 2500-76XF
- 96 Zone 2500-96XF
- 116 Zone 2500-116XB

Dimensions

2500-12F, 16F:

- **Front Frame:** 16.06" H x 14" W x 3.07" D

- **Back Box:** 15.64" H x 12" W x 3" D

2500-28F, 36F, 56XF, 76XF, 96XF, 116XF:

- **Front Frame:** 21.13" H x 25" W x 3.06" D

- **Back Box:** 20.66" H x 23" W x 3" D

Specifications:

Mounting: Surface, flush, or desk

Design: Powder coated steel enclosure with twist lock closure

Warranty: 2 Years

Contact Us for Larger Projects

CODE COMPLIANCE:

- ADA, ASME A17, and B44 code compliant

WIRING REQUIREMENTS:

- Sub-Master Stations to Distribution Module: single pair
- Machine Room Phone (2300-630RC) (single pair)

PHONE CAPABILITIES:

- Works with 2100 series SmartPhones
- Audible alert sounds when phones place a call until Base Station or Sub-Master Station joins conversation
- LEDs indicate which phones have initiated a call
- Rescue personnel can communicate with individual phones and outside party
- Calls wait in queue until previous call is disconnected
- Includes handset for communication to elevators

ADDITIONAL FEATURES:

- Can be configured with the main Base Station, multiple Sub-Master Stations (available in desk, surface, or flush mount) and Machine Room Phones (2300-630RC)