SmartView Two-Way Elevator Visual Communication System



P2500-205BSV, 2500-210BSV, 2500-205FMSV, 2500-210FMSV



Flush Mount Part #s:

- 2500-205FMSV (up to 5 Call Boxes)
- 2500-210FMSV (up to 10 Call Boxes)

Front Frame Dimensions: 21.13" H x 25" W x 3.06" D Back Box Dimensions: 20.66" H x 22.99" W x 3" D

Surface Mount Part #s:

- 2500-205BSV (up to 5 Call Boxes)
- 2500-210BSV (up to 10 Call Boxes)

Dimensions: 21.03" H x 20.3" W x 5.19" D

Style:

- · Powder coated steel enclosure
- Twist lock closure for use with Fireman's lock (not provided)
- · Coil cord
- Pre-configured to the SmartView Software

Contact Us for Larger Projects

CODE COMPLIANCE:

- ADA, ASME A17, and B44 code compliant
- Volume control handset meets ADA requirements

POWER REQUIREMENTS:

- · Designed for 120vac power
- Built-in battery backup recharges from 120vac power (allows for a minimum of 4 hours talk time upon power loss)

WIRING REQUIREMENTS:

• Run twisted and shielded 4 wire set from each SmartPhone to unit and one standard phone line to the outside world

PHONE CAPABILITIES:

- Telephone Line Voltage: 24v-48v
- Requires a single analog (POTS, PBX, or central office phone line) or digital phone line.

If used on a VoIP or cellular network, you must purchase a RATH® 2100-LTEGSM4 Gateway Device.

DISPLAY & CONTROLLER

- Display requires 9v@1.2A and includes 120v plug-in transformer
- Mini PC requires 12v@1.5A and includes 120v plug-in transformer
- Requires back-up power or RATH® RP7700107
- Ethernet connection
- HDMI connection for display

Specifications:

Mounting: Surface or Flush

Design: Powder coated steel enclosure with twist lock

closure

Warranty: 2 Years

Features:


- · Easy to use push buttons
- · Passively monitor communications between elevators and the outside world via the LEDs
 - 1. Solid lit LED indicates there is an emergency call in progress
 - 2. Slow blinking LED indicates there is a call on hold
- · Audible alert when elevator initiates a call to the unit
- · Includes relay contact that trips if any SmartPhone has been activated
- The unit is able to:
 - 1. Call into all or individual elevators as needed
 - 2. Join existing conversations between cars and outside world
 - 3. Hang up and original conversation will continue
 - 4. Terminate outside world so it is only talking to the elevator or terminate the call with all parties entirely
- Single location device located in machine room or lobby (for multiple locations see SmartView Command Center)

SmartView SmartRescue



P2500-205BSV, 2500-210BSV, 2500-205FMSV, 2500-210FMSV

Flush Mount:







Front View

Angled View

Flush Mount:

