

IP Sub-Master Station



Sub-Master Cabinet (Surface Mount)



- 10 Zone 2500-10B
- 16 Zone 2500-16B
- 32 Zone 2500-32B
- 48 Zone 2500-48B
- 64 Zone 2500-64XB
- 80 Zone 2500-80XB
- 96 Zone 2500-96XB
- 112 Zone 2500-112XB
- 128 Zone 2500-128XB

Dimensions:

- **2500-10B, 16B:** 15.14" H x 12" W x 6.19" D
- **2500-32B, 48B, 64XB, 80XB, 96XB, 112XB, 128XB:** 21.03" H x 20.3" W x 5.19" D

Sub-Master Cabinet (Flush Mount)



- 10 Zone 2500-10F
- 16 Zone 2500-16F
- 32 Zone 2500-32F
- 48 Zone 2500-48F
- 64 Zone 2500-64XF
- 80 Zone 2500-80XF
- 96 Zone 2500-96XF
- 112 Zone 2500-112XF
- 128 Zone 2500-128XF

Dimensions:

- **2500-10F, 16F:**
 - **Front Frame:** 16.06" H x 14" W x 3.07" D
 - **Back Box:** 15.64" H x 12" W x 3" D
- **2500-32F, 48F, 64XF, 80XF, 96XF, 112XF, 128XF:**
 - **Front Frame:** 21.13" H x 25" W x 3.06" D
 - **Back Box:** 20.66" H x 23" W x 3" D

Sub-Master (Desk Mount)



- 10 Zone 2500-10D
- 16 Zone 2500-16D
- 32 Zone 2500-32D
- 48 Zone 2500-48D
- 64 Zone 2500-64XD
- 80 Zone 2500-80XD
- 96 Zone 2500-96XD
- 112 Zone 2500-112XD
- 128 Zone 2500-128XD

CODE COMPLIANCE:

- International Building Code (IBC)
- National Fire Protection Association (NFPA)
- Americans Disabilities Act (ADA)

PHONE CAPABILITIES:

- Audible alert sounds when phones place a call until Base Station or Sub-Master Station joins conversation
- LEDs indicate which Call Boxes have initiated a call
- Rescue personnel can communicate with individual Call Boxes and outside party
- Calls wait in queue until previous call is disconnected

POWER & WIRING REQUIREMENTS:

- Command Center and Sub-Master Stations are powered from PoE
- Command Center and Sub-Master Stations to Distribution Module: IP (PoE)

ADDITIONAL FEATURES:

- Includes handset for communication to Call Boxes
- Can be configured with the main Command Center and multiple Sub-Master Stations (available in desk, surface, or flush mount)

Specifications:

Mounting: Surface, Flush, or Desk

Design: Powder coated steel enclosure with twist lock closure

Warranty: 2 Years