

Keypad Programming

Step 1: Begin Program Mode

- a. Press **Enter**

Step 2: System Operation (a or b)

- a. For SoundNet press **1, 9, Enter, 6**
b. For Standard Operation press **1, 9, Enter, 1**

Step 3: Program Emergency Numbers

- a. Press **1, Enter**, (phone number), **Stop**
b. SoundNet press **2, 1, Enter**, (11 digit Soundnet Code), **Stop**. To program numbers 2 - 5, repeat Step 3 a.

Example: To program emergency number 2, press **2, Enter**, (phone number), **Stop**.

Note: If installed on a ring down line (no dial tone) do not program a phone number, press the following: **1, 9, Enter, 2** (automatically sets the timer for 3 minutes).

Step 4: Program Location Message

- a. To turn on message press **1, 3, Enter, 2**
b. Press **6, Record**, wait for the "beep", then speak message, **Stop**. To replay message, press **6, Play/Pause**.

- c. Program frequency of message, press **1, 3, Enter, __**
0 = No message
2 = Plays message (2) times (default)
3 = Plays message until receiving party presses *

Note: Called party can replay message by pressing *,*.

Step 5: Exit Program Mode

- a. Press **Stop** for 3 seconds

Remote Programming

(Landline Phone Recommended)

Step 1: Begin Program Mode

- a. Call into phone
b. After first simulated ring, press **#, #**
c. Key in security code (default is **1111**)

Step 2: System Operation (a or b)

- a. For SoundNet press **1, 9, *, 6**
b. For Standard Operation press **1, 9, *, 1**

Step 3: Program Emergency Numbers

- a. Press **1, *,** (phone number), ***, #**
b. SoundNet press **2, 1, *,** (11 digit SoundNet Code), ***, #**

To program numbers 2 - 5, repeat Step 3 a.

Example: To program emergency number 2, press **2, *,** (phone number), ***, #**. For a pause, press **#, ***.

Note: If installed on a ring down line (no dial tone) do not program a phone number, press the following: **1, 9, *, 2** (automatically sets the timer for 3 minutes).

Step 4: Program Location Message

- a. To turn on message press **1, 3, *, 2**
b. Press **6, ***, wait for the "beep", then speak message, **#**. To replay message, press **6, #**
c. Program frequency of message, press **1, 3, *, __**

- 0** = No message
2 = Plays message (2) times (default)
3 = Plays message until receiving party presses *

Note: Called party can replay message by pressing *,*.

Step 5: Exit Program Mode

- a. Press ***, #, 0** (you will hear beep, beep) ***, #**

Optional Programming Features

Program Talk Timer

(Default is 5 minutes, ring down is 3 minutes)

Keypad:

Press **8, ENTER**, (3 digit number in minutes)

Remote:

Press **8, *,** (3 digit number in minutes)

Example: 2 minutes = 002

Note: After talk time expires, phone will prompt called party to extend call for 3 minutes.

Phone Line Check: (Default is 10 minutes)

Keypad: Press **3, 4, Enter**, (4 digit number in HH:MM)

To turn off, press **23, Enter, 3, 23, Enter, 7284, 11, Enter, 2**

Remote: Press **3, 4, *,** (4 digit number in HH:MM)

To turn off, press **23, *, 3, 23, *, 7284, 11, *, 2**

Example: 20 minutes = 0020, 10 hours = 1000

Consolidator Feature: (Allows up to (10) SmartPhones on a single telephone line and toggle between them from an outside call)

Step 1: Begin Program Mode

- a. Press **Enter**

Step 2: Program ID Numbers for Phones 1-5

- a. Press **7, Enter**
b. Press ***, 1-5** for corresponding elevator 1-5

Step 3: Program ID Numbers for Phones 6-10

- a. Press **7, Enter**
b. Press **#, 1-5** for corresponding elevator 6-10

Step 4: Exit Program Mode

- a. Press **Stop** for 3 seconds

Step 5: Confirm Consolidator Operation

- a. Dial phone number connected to SmartPhones: All phones will answer
b. To select individual phone:

- | | |
|-----------------------|----------------------|
| Press *1 (Phone #1) | Press #1 (Phone #6) |
| Press *2 (Phone #2) | Press #2 (Phone #7) |
| Press *3 (Phone #3) | Press #3 (Phone #8) |
| Press *4 (Phone #4) | Press #4 (Phone #9) |
| Press *5 (Phone #5) | Press #5 (Phone #10) |
| Press *0 (All Phones) | |