

SmartView Command Center



Flush Mount

Part #s:

- 12 Zone 2500-12RCFSV
- 28 Zone 2500-28RCFSV
- 56 Zone 2500-56XRCFSV
- 96 Zone 2500-96XRCFSV
- 16 Zone 2500-16RCFSV
- 36 Zone 2500-36RCFSV
- 76 Zone 2500-76XRCFSV
- 116 Zone 2500-116XRCFSV

Front Frame: 21.13" H x 25" W x 3.06" D

Back Box: 20.66" H x 22.99" W x 3" D



Surface Mount

Part #s:

- 12 Zone 2500-12RCSV
- 28 Zone 2500-28RCSV
- 56 Zone 2500-56XRCSV
- 96 Zone 2500-96XRCSV
- 16 Zone 2500-16RCSV
- 36 Zone 2500-36RCSV
- 76 Zone 2500-76XRCSV
- 116 Zone 2500-116XRCSV

Dimensions: 21.03" H x 20.3" W x 5.19" D



Code Compliance:

- ADA, ASME A17, and B44 code compliant

Wiring Requirements:

- Sub-master stations to distribution module: single pair smartphones to distribution module: single pair

Phone Capabilities:

- Includes handset for communication to elevators
- Audible alert sounds when phones place a call until base station or sub-master station joins conversation
- LEDs indicate which phones have initiated a call
- Rescue personnel can communicate with individual phones and outside party
- Calls wait in queue until previous call is disconnected

Additional Features:

- Can be configured with the main base station, multiple sub-master stations (available surface or flush mount)
- Works with our model 2100 series smartphones

SmartView Controller & Controller Features:

- Power connections: 120v
- Ethernet connection
- HDMI connection for display

When utilizing a Sub-Master with this system, you must provide a static IP address for both the master and each sub-master visual communication.