

# SAFE-AN-1002

Remote Annunciator for Code Required Alarm Notifications



## Compact, compliant and compatible.

- Connects to any Safe-Com BDA or head end.
- Provides visual (LEDs) & audible annunciation to alert local personnel of a system issue.
- A single CAT5 cable delivers power, backup power & alarm connection for quick & easy installation.
- Magnetic switch provides simple means of testing LEDs and temporary muting of alarm.
- Additional form-C relays provided for external notifications/connections to fire panel.




## Specifications

|                              |   |
|------------------------------|---|
| Front Panel Dimensions       | 6.5 x 5.75 x 0.08 inches                  |
| Recessed Gang Box Dimensions | 4.5 x 4.5 x 3 inches                      |
| Enclosure                    | NEMA 4                                    |
| Mounting                     | Recessed or flush                         |
| Max Distance from BDA        | 1,000 feet*                               |
| Power                        | Provided by the BDA                       |
| Connection                   | 4-pair 24 AWG CAT 5 cable, RJ45 connector |

\*Tested using 4 pair, 24AWG CAT5 wire, model 5ECMRWHT\_1kbx CAT5E riser cable from TrueCable(TM). Test prior to installation.

## Enclosure and Mounting



### 1 Connecting the Panel

Four screws (provided) attach the front panel to gang box enclosure.

### 2 Mounting the Gang Box Enclosure

Unit can be mounted inside a cutout in a sheetrock wall for flush mounting or surface mounted on a wall using through-holes in the back of the box.

### 3 Cable Feed-through

With the front panel detached from the box, feed the CAT5 cable and alarm twisted pairs through the feed-through mechanism, then remount the front panel onto the enclosure.

# AVIRE

N56 W24720 N. Corporate Circle Sussex, WI 53089  
800-451-1460 | sales.us@avire-global.com  
avire-global.com/en-us