

Reprogramming on site using Memcom Keypad

OPTION 1: 453 Memcom with '1 Programming' shown on the display.

Programming steps through menu:

STEP 1 Accessing Memcom programming:

1. Press 1 .
2. Screen shows 'Use * to go back or use # to accept' (this will disappear after a couple of seconds).

STEP 2 Selecting Alarm/Technical & Background numbers & deleting:

1. To program Alarm n01, (go to *STEP 3*).
2. Select Alarm n02, followed by #, go to *STEP 3* to program or press down arrow to delete.
3. Select Alarm n03, followed by #, go to *STEP 3* to program or press down arrow to delete.
4. Select Alarm n04, followed by #, go to *STEP 3* to program or press down arrow to delete.
5. Select Technical Alarm, followed by #, go to *STEP 4* to program or press down arrow to delete.
6. Select Background Alarm, followed by #, go to *STEP 4* to program or press down arrow to delete.

STEP 3 Programming Alarm number:

1. Type in your new alarm emergency number followed by #
2. Select Guided or Unguided (see NOTE below) followed by #

Guided: Plays instruction message for the operator, includes option to play location, if recorded.

UnGuided: Plays no message.

Exit programming by repeat pressing of the * key.

Example: Programming 1 number as Guided:

Press 1 > select tel numbers, press # > select alarm n01, press # > type in alarm number eg 0123456789, press # >

Guided, Press # > press * > press * > press *

STEP 4 Monitoring:

(Technical and Background Monitoring numbers when used with the Avire HUB.

(Avire HUB number is 03308084733)

1. Type in Technical number, followed by #
2. Select P100, followed by #
3. Follow the On Screen message by pressing to duplicate number to Background (Recommended).

OPTION 2: Memcom 450/453 using access code.

STEP 1 Accessing Memcom programming:

1. Press *1234# (Access Code default).
2. Using the UP/Down arrows will help navigate through the settings.
3. If Alarm numbers 12- 14 and 15/16 Technical/Background numbers are not required, make sure these values are deleted by pressing * then #

STEP 2 Programming & deleting:

1. Press the UP arrow once this will take you to the alarm number 1 (*11)
2. Enter new telephone number and then press # to confirm (Guided message).
E.g., (11) 0123456789# (3 confirmation beeps are heard)
3. Press the UP arrow once this will take you to alarm number 2 (*12)
4. Enter new telephone number and then press # to confirm or * # to delete.
5. Press the UP arrow once this will take you to alarm number 3 (*13)
6. Enter new telephone number and then press # to confirm or * # to delete.
7. Press the UP arrow once this will take you to alarm number 4 (*14)
8. Enter new telephone number and then press # to confirm or * # to delete.
9. Either exit by pressing # then *01# or if Technical/Background is required continue to *Step 4*.

STEP 3 Monitoring:

1. Press the UP arrow once this will take you to Technical Alarm number 5 (*15)
Enter Technical number followed by **3 (P100, HUB press # to confirm or * then # to delete.
Avire HUB number 03308084733)
example 03308084733**3
2. Press the UP arrow once this will take you to Background number 6 (*16)
Enter Background number followed by **3 (P100, HUB) press # to confirm.
Or * # to delete (Avire HUB number 03308084733)
example 03308084733**3

Pressing # key after Telephone numbers sets Alarm as Guided: Plays instruction message for the operator includes option to play location if recorded.

Adding **0 followed by # sets the Telephone number as UnGuided: Plays no message.
E.g.123456789**0

STEP 4 Exit Programming:

1. Press #, then press *01 #

Example: Programming 1 number as Guided:

Press *1234# > Press 'up arrow' once, alarm 1 > type in Alarm number *example, 0123456789* > Press # > Press # > Press *01#