

Memcom+ Re-programming

Reprogramming on site using Memcom Keypad

OPTION 1: 453 Memcom with '1 Programming' shown on the display

STEP 1 (Accessing Memcom programming)

1. Press 1

2. Screen shows 'Use * to go back or use # to accept' (this will disappear after a couple of seconds)

STEP 2 (Selecting Alarm/Technical & Background numbers & deleting)

1. Select TEL. numbers, followed by #

2. Select Alarm n01, followed by # (go to STEP 3)

3. Select Alarm n02, followed by #, go to STEP3 to program or press down arrow to delete

4. Select Alarm n03, followed by #, go to STEP3 to program or press down arrow to delete

5. Select Alarm n04, followed by #, go to STEP3 to program or press down arrow to delete

6. 6. Select Technical Alarm, followed by #, go to STEP 4 to program or press down arrow to delete

7. 7. Select Background Alarm, followed by #, go to STEP 4 to program or press down arrow to delete

STEP 3 (Programming Alarm number)

1. Type in your new alarm emergency number followed by #

2. Select Guided or Unguided (see NOTE below) followed by

Guided: Plays instruction message for the operator, includes option to play location, if recorded.

UnGuided: Plays no message

Exit programming by repeat pressing of the * key

STEP 4 (Programming Tech and Background Monitoring numbers, Avire HUB)

1. Type in Technical number, followed by #
2. Select Memco, followed by #
3. Follow the On Screen message by pressing to duplicate number to Background (Recommended)

Example: Programming 1 number as Guided

Press 1 > select tel numbers, press # > select alarm n01, press # > type in alarm number eg 0123456789, press # > Guided, Press # > press * > press * > press*

OPTION 2: Memcom 450/453 using access code

STEP 1 (Accessing Memcom programming)

1. Press *1234# (Access Code default)
2. Using the UP/Down arrows will help navigate through the settings
3. If Alarm numbers 12- 14 and 15/16 Technical/Background numbers are not required, make sure these values are deleted by pressing * then #

STEP 2 (Programming & deleting)

1. **Press the UP arrow once this will take you to the alarm number 1 (*11)**

2. **Enter new telephone number and then press # to confirm (Guided message) E.g. (11) 0123456789# (3 confirmation beeps are heard)**
3. Press the UP arrow once this will take you to alarm number 2 (*12)
4. Enter new telephone number and then press # to confirm or * # to delete
5. Press the UP arrow once this will take you to alarm number 3 (*13)
6. Enter new telephone number and then press # to confirm or * # to delete
7. Press the UP arrow once this will take you to alarm number 4 (*14)
8. Enter new telephone number and then press # to confirm or * # to delete
9. Press the UP arrow once this will take you to Technical Alarm number 5 (*15)
10. Enter Tech telephone number followed by **1 press # to confirm or * then # to delete (**1 is a PC protocol/HUB for monitoring)
11. Press the UP arrow once this will take you to Background number 6 (*16) Enter Background telephone number followed by **1 press # to confirm or * then # to delete (**1 is a PC protocol/HUB for monitoring)

Pressing # key after Telephone numbers sets Alarm as Guided: Plays instruction message for the operator includes option to play location if recorded

*Adding **0 followed by # after Telephone numbers sets Alarm as UnGuided: Plays no message*

*E.g.123456789**0*

STEP 3 (Exit Programming)

1. Press #, then Press *01 #

Example: Programming 1 number as Guided

Press *1234# > Press 'up arrow' once, alarm 1 > type in Alarm number e.g. 0123456789 > Press # > Press # > Press *01#